

INTRODUCTION

LUXTECH's LUXlens Linear Batwing Optic and mounting clips are designed to seamlessly integrate with our LUXroll CC product. This guide highlights the best installation practices and steps to ensure a successful and rapid install

CONTACT US

For assistance, please reach out at sales@luxtech.com


RECOMMENDED TOOLS



Heavy Duty
Rubber Cutter




Clip Alignment Tool
(Provided by LUXTECH)



PROCEDURE


1



Install LUXroll into fixture

Once the full length of LUXroll is adhered to the fixture, firmly press to ensure full-contact adhesion - the tape is pressure sensitive.


2



Place Alignment Clip onto LUXroll

Use alignment tool to ensure clips are installed at proper location.

3



Install mounting clips onto LUXroll

Remove adhesive backing and firmly press and adhere to LUXroll.


4



Space clips accordingly

Maximum spacing between clips is 12".
Minimum of 2 clips per optic.


5



Cut optic to size as needed

Measure the length of optic required. If the needed length is >47", multiple pieces of optic can be installed end to end. Make sure that each optic piece is attached with at least 2 clips.

6



Snap optic into mounting clips

Align the optic with the module from above and press down firmly. A click will indicate that the optic is fully seated.